

PORTAVALIGIE LATERALE SPECIFICO - SPECIFIC TUBULAR SIDE-CASE HOLDER
 PORTE-VALISES LATÉRAUX SPÉCIFIQUE - SPEZIFISCHES STAHLROHR-SEITENTRAEGER
 PORTA MALETAS LATERALES ESPECÍFICO

BMW F650GS 2000-2007

BMW G650GS 2011

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS
 INSTRUCCIONES DE MONTAJE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

ATTENZIONE - WARNING - ATTENTION

IL SUPPORTO "A" VA INSERITO TRA IL FIANCHETTO ED IL SILENZIATORE.

THE UPPER SUPPORT "A" MUST BE INSERTED BETWEEN SIDE PANEL AND THE SILENCER

LE SUPPORT "A" DOIT ETRE INSERE' ENTRE LE COTE PLASTIQUE ET LE POT.

①



SUPPORTO
 SUPPORT
 SUPPORT
 HALTERUNG
 SOPORTE

Q.TY n.2(Dx-Sx)


②



PONTE POSTERIORE
 REAR BRIDGE
 PONT POSTERIEURE
 VERBINDUNGSGROHR
 PUENTE TRASERO

Q.TY n.1


③



VITE TBEI M8x20mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.2


④



VITE TBEI M6x16mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.2


⑤



VITE TBEI M8x25mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.2


⑥



VITE TEF M8x25mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.2


⑦



RONDELLA Ø6mm
 WASHER Ø6mm
 RONDELLE Ø6mm
 SCHEIBE Ø6mm
 ARANDELA Ø6mm

Q.TY n.2

⑧



RONDELLA Ø8mm
 WASHER Ø8mm
 RONDELLE Ø8mm
 SCHEIBE Ø8mm
 ARANDELA Ø8mm

Q.TY n.2

⑨



DISTANZIALE Ø14x3mm
 Foro Ø8,5mm, V379
 SPACER
 ENTRETOISE
 DISTANZSTUECK
 DISTANCIADOR

Q.TY n.2


⑩



FISHER Ø30X25
 RIB. 23,7x21 Ø17,4
 V665
 EXPANDING TUBE INSERT
 CHEVILLE
 ELASTISCHER ROHREINSATZ
 TACO

Q.TY n.2

⑪



CONO FILETTATO
 Ø20,4 a 18,8 M8
 V667
 THREADED CONE
 CONE FILETE
 KEGEL GEWINDE
 CONO ROSCADO

Q.TY n.2

⑫

COMPONENTI ORIGINALI
 ORIGINAL PARTS
 PARTIES ORIGINALES
 ORIGINAL BAUTEILE
 COMPONENTES ORIGINALES

Q.TY n.-

